

SMARTYCAM START-UP GUIDE

1) Install SmartyCam

Put the camera in the desired position and fix it (even using the optional brackets): the display shows a frame preview.

2) Calibrate the accelerometer (see paragraph 6.3.1.1. SmartyCam user guide)

3) Set Auto-REC function (paragraph 6.4.2. SmartyCam user guide)

With Auto-REC recording starts automatically when acceleration exceeds a threshold value to be selected among low (0.2 G), med (0.4 G) and high (0.8 G).

That's all: now it is possible to shoot your first video

If you want to get laptimes and overlay them on videos you have to fix start/finish point. This operation can be done manually on SmartyCam display: simply press Menu>>"Lap Management">>"Fix". Once the point is fixed, every time SmartyCam passes that point, a laptime will be registered.